

Ohuhu Sliding Barn Door Hardware

User Manual

Thanks for choosing Ohuhu! Please read this user manual carefully before use and keep for future reference.

Safety Precautions

- **Make sure the door to be installed has a floor guide slot.**
- Please handle all hardware carefully during installation.
- Do not use this hardware to mount a door heavier than 270 lbs.
- Store this product in a dry, ventilated area before use.

Description

Sliding barn door hardware is exploding in popularity, and for good reason— it's a great way to give your home a rustic feel without sacrificing style. You can get rid of squeaky doors once and for all with the high-quality steel track and premium nylon rollers. It's also fireproof, waterproof, rustproof, and perfect for outdoor use. This sliding barn door hardware is just what you need to try out the trend!

Package Contents



- 2x 3.3ft Rail
- 5x Sleeve for Rail
- 5x Screw for Rail
- 5x Screw Nut For Rail
- 5x Sleeve Anchor For Rail
- 2x Roller

4x Screw for Roller
4x Screw Nut For Roller
8x Gasket For Roller
2x Door Stopper
2x Anti-Jump Discs
2x Screw for Anti-Jump Discs
1x Floor Guide
2x Screw for Floor Guide
2x Sleeve Anchor for Floor Guide
1x Spirit Level
1x Hexagon Wrench
1x User Manual

Installation Instructions



1. Place the hanger on one side of the door. The distance between the top edge of the door and the top hole of the hanger should be 1.6 inches. Mark the position of the holes with a pencil.



2. Use a drill to drill the position of the holes.



3. Place the gaskets on the screws and screw them in tightly. Put the gaskets on the screws and plug the screws into the holes. Place an additional gasket over the screw and mount the nuts. (see diagram below).



4. Repeat steps 1-3 on the other side of the door.



5. Screw the anti-jump discs on both sides of the door. (see diagram above)



6. Use a pencil to mark the wall 1.7 inches above the door. This mark is where the rail will be installed.




7. The distance between the leftmost hole of the rail and the door frame must be 4.7 inches. Use a pencil to mark the location.



8. Line up the rail with your marks from steps 6 and 7. Use the included spirit level to make sure the rail is straight. Mark the positions of the holes with a pencil.



9. Use an electric drill to drill the marked positions.



10. Place the sleeve anchors into the holes. Mount the rail with screws, making sure they are screwed in tightly.



11. Fix the rail on the wall with spanner.




12. Mount the door stoppers on each end of the rail with the hexagon wrench.



13. Hang the door on the rail.




14. Turn the anti-jump discs under the rail.



15. Pull the door all the way to one side. Place the floor guide where the door ends and use a pencil to mark the locations of the holes.



16. Place the sleeve anchor into the holes, insert the screws, and mount the floor guide.



17. Screw the floor guide down tightly.



18. Enjoy your new door!